



Computer vision in the new era of Artificial Intelligence and Deep Learning

Visión por computador en la nueva era de la Inteligencia Artificial y el Deep Learning

Rubén Usamentiaga*, Alberto Fernández°

- * University of Oviedo
- ° TSK

Gijón (Spain) 5 – 16 April 2021



Google Colab



Take both images and videos from webcam in Colab



- take image from webcam as numpy array.ipynb
- <u>take video from webcam in colab.ipynb</u>



- take image from webcam as numpy array.ipynb
- <u>take video from webcam in colab.ipynb</u>



Taking images/videos from webcam in Colab

☐ OpenCV provides cv2.VideoCapture() object to capture live
stream with camera. See this script to see how to use
cv2.VideoCapture().
oxdot However, cv2.VideoCapture() does not work in Colab, because the
previous method can only access hardware (e.g. webcam)
connected locally.
☐ The solution is to code our own methods. For similar approaches
you can check the following links:
"VideoCapture in Colab: How do i use cv2.VideoCapture(0) in
google colab"
"Camera Capture": This function does not return the image. It
takes the image from the webcam and saves the file on disk
"Direct access to your webcam inside Colab"

Taking images from webcam in Colab

See the accompanying notebook

"take_image_from_webcam_as_numpy_array.ipynb"

to see the implementation of the method take_photo(), which returns a numpy

array.

```
img = take_photo(quality=0.8)

# Printing the shape of the image
# This returns, for example: (480, 640, 3)
print(img.shape)
```

```
from google.colab.patches
import cv2_imshow
cv2_imshow(img)
```



the returned image is in RGB format

```
img_bgr = img[:, :, ::-1]

cv2_imshow(img_bgr)
```



OpenCV works in BGR format

Taking video from webcam in Colab

<u>This repository</u> provides the required functionality to take video from webcam. To install it, we make use of download_and_execute_file() function (see accompanying notebook take_video_from_webcam_in_colab.ipynb). The file that is going to be executed is located here and contains the implementation.

```
fname = 'colab_utils.py'
url = 'https://raw.githubusercontent.com/albertofernandezvillan/computer-
vision-and-deep-learning-course/main/assets/colab_utils/colab_utils.py'

download_and_execute_file(fname, url, params= "", execute=True,
show_content=False)
```

Once installed, we can use our own videoGrabber, and use it as follows:

```
total_iter=20
vid = videoGrabber(showVideo=False)
try:
    n_iter = 0
    while n_iter <= total_iter:
        n_iter += 1
        image_np = np.array(vid(0))
        imshow(image_np)
finally:
    vid(stop=True)</pre>
```

Google Colab



Take both images and videos from webcam in Colab